#### Better Results. Less Chemistry.

Hubbard-Hall Inc. • 563 South Leonard Street, Waterbury, CT 07608 • HubbardHall.com • 800-648-3412

**Product Bulletin** 

Product Name: Stripol TL-15 Product Code: 2701004 Revision Date: July 26, 2021

# Stripol TL-15

Stripol TL-15 is a liquid, acidic, non-peroxide product developed to strip solder or other lead-tin alloys from copper surfaces either in an immersion or spray operation.

Stripol TL-15 replaces the unstable and somewhat hazardous solder strippers that are based on Hydrogen Peroxide or ferric nitrate. Please note, however, that Stripol TL-15 has a shelf life of three months from date of manufacture.

### **Features & Benefits**

No peroxide	Safer to use
	Less sludge in waste-water
	treatment; lower total process
	cost

# **Operating Conditions**

Concentration	Use as received at full strength
Temperature range	70°F – 90°F (21°C – 32°C)
Time	5 – 15 min
Equipment	Do not use fiberglass
	equipment
	Tanks may be constructed of
	Polypropylene, Polyethylene,
	rubber or Koroseal lined
Rack and baskets	Plastisol covered steel, brass
	or copper
	Note: Stripol TL-15 has a
	minimal effect on copper
Ventilation	Desirable
Agitation	Desirable; solution or work
	agitation will decrease stripping









#### Better Results. Less Chemistry.

Hubbard-Hall Inc. • 563 South Leonard Street, Waterbury, CT 07608 • HubbardHall.com • 800-648-3412

**Product Bulletin** 

Product Name: Stripol TL-15 Product Code: 2701004 Revision Date: July 26, 2021

time

#### Control

The oxidizer in this product will be slowly depleted. When stripping speed has dropped to 25 to 35% of the initial rate - make up a new solution.

# **Waste Disposal**

Neutralize the spent Stripol TL-15 solution with a caustic soda solution to a pH between 7.0 to 9.0 to precipitate the solder. Filter or decant the solution. The metallic sludge must be hauled away by an approved carrier. The alternative is to have the spent solution taken away.

### **Caution**

Stripol TL-15 is an acidic, corrosive solution. Avoid skin, eye and oral contact. Wear protective clothing, gloves and goggles when handling the product. Flush exposed areas immediately with clean, cold water. Contact a doctor immediately in case of injury.

WARRANTY: THE QUALITY OF THIS PRODUCT IS GUARANTEED ON SHIPMENT FROM OUR PLANT. IF THE USE RECOMMENDATIONS ARE FOLLOWED, DESIRED RESULTS WILL BE OBTAINED. SINCE THE USE OF OUR PRODUCTS IS BEYOND OUR CONTROL, NO GUARANTEE EXPRESSED OR IMPLIED IS MADE AS TO THE EFFECTS OF SUCH USE, OR THE RESULTS TO BE OBTAINED.

### Our people. Your problem solvers.

For more information on this process please call us at 1-800-648-3412

or techservice@hubbardhall.com













